



## JKS OPEN PRE-GLUED RUBBER APRONS INSTRUCTION MANUAL



1. Put the apron into the work position.
2. Avoid touching the skived surface.
3. Only a light coat of **JKS EP** activator liquid should be put on both skived edges with a thin brush or with a pen on the full skived area.
4. Let the activator dry for approx. 10-15 seconds until the activator is not more shiny.
5. Stick the ends carefully by applying uniform pressure by fingers or better with a clamp by around 45 seconds to 1 minute.
6. To use a clamp is advisable.
7. Leave the joint dry for around 5-6 minutes.
8. The strength increases with the drying time. Drying time is also depending on temperature and humidity.

Note: the reactivator should be fresh!