

JKS OPEN SKIVED RUBBER APRONS
INSTRUCTION MANUAL
ENDLESS MAKING OF APRONS WITH CLAMP



1. Rapid Glue should be used – we recommend Sicomet 8400 glue.
2. Skived surface should be free from dirt or oil.
3. The skived edges should be inserted in the clamp.
4. The arrows of the skived edges should be lines of the other end.
5. A drop of rapid glue should be given on the lower skiving area.
6. No glue should be given on the upper edge.
7. The clamp should be closed.
8. The apron is ready for use within 2 - 3 minutes.

Note: In case mill people don't use clamps and close the Apron with their fingers, the operator should use finger tips.