

JKS 933 WHITE OPEN PRE-GLUED LEATHER APRONS
ENDLESS MAKING WITH WATER ONLY
METHODE OF STICKING



1. Put the aprons into the work position
2. Light coat of water or saliva should be put on both pre-glued edges, like a stamp
3. Stick the ends carefully by applying uniform pressure with fingers by around 30 seconds.
4. Aprons are ready for use within around 3 minutes of drying time.